

User Manual 7Chakra Activator



Please read the manual before using the tools.

Version 1.0

Table of Contents

1	G	eneral Notes2	!
	1.1	Product Feature and Intend Use2	
	1.2	Warning2	2
	1.3	Warranty2	2
	1.4	Precautions	}
	1.5	Maintenance3	
	1.6	Product Includes4	ŀ
2	Те	chnical Data	
	2.1	Specifications	
	2.2	Overview and Function6	;
3	Se	tup and Operation Instruction	
	3.1	Setup	,
	3.2	Operation	3
	3.	2.1 Charging	
4	Fo	ault Diagnosis	

1 General Notes

1.1 Product Feature and Intend Use

Thank you for using Light Mandalas Product. 7Chakra Activator has been in good condition before leaving factory.

7Chakra Activator is a highly efficient and fast-acting device for structuring the specific area and normalizing the general energy and psycho-emotional state of a person.

- Activating all chakras of the body and cleaning aura to achieve balance.
- Activating and transmitting powerful energy vibrations from the natural forces and spiritual realms of the universe of the Earth to enable everyone to obtain these high-quality energies.
- The impact of spiritual forces, colors and wavelengths on water may generate energy activation.

1.2 Warning

Pay close attention to each safety REMARK and WARNING statement in the manual. This manual contains important operation information.

This product is in perfect condition before delivery, please check all accessory when unpacking the unit.

In order to safely and effectively use this product, please be sure to read this "User Manual" for the proper method usage.

For your eyes safety, please wear light protective goggles and avoid light to expose to your eyes.

1.3 Warranty

Each single product passes through a quality process. Nevertheless, if failures occur, contact the customer service at once. The product is under 12 months (1 year) warranty effectively according to the delivery date stated on the warranty card.

Warranty does not apply to damages, which result from misuse or neglect. The warranty also expires if you dismantle the product or failed to provide the warranty card. The manufacturer is not liable for consequential damage or in case of a non-intended use of the product.

If a failure occurs during the warranty period, the product will be replaced or repaired. The manufacturer reserves the right to exchange components of the product instead of repairing it. If the failure results from misuse or neglect, the user must pay for all cost that may occur. The freight cost and other costs will be depending on which Term & Conditions criteria the product falls into. **Import tax and Customs clearance duty cost is not included in the term of warranty**. In that case, you may ask for an estimated cost beforehand.

1.4 Precautions

- 1. Please check 7Chakra Activator for damage during shipping. Do not use the device if any damage is discovered. If the device is damaged, please contact the dealer or Light Mandalas immediately
- 2. Do not disassemble or modify the device in any case.
- 3. Do not use the device outdoors when rains
- 4. Places the device in a well-ventilated area.
- 5. Keep dry and avoid excessive humidity, heat or dust.
- 6. Do not look directly into the light to avoid harm eyes.
- 7. Disconnect power when cleaning the tool or not in use.

1.5 Maintenance

- 1. Clean with soft cloth, humid tissue moistened with water or a water-based glass cleaner.
- 2. In order to guarantee the fixture works properly, it is essential to keep it clean.

1.6 Product Includes



2 Technical Data

2.1 Specifications

•	
Product name	7Chakra Activator
Color	White / Gold
Material	Plastic ABS + Resin + Glass
Input Voltage	DC 5V / 2A
Charging Interface	USB Type-C
Battery Type	Built-in 3.7V 1000mAh Polymer Battery
Light Led	RGBUV 18W
Red Wave Length	220-225nm
Green Wave Length	520-525nm
Blue Wave Length	460-465nm
UV Wave Length	400-430nm
frequency	998Hz - 48600Hz – 171000Hz
Length	90.24 mm.
Width	90.24 mm.
Height	26.35 mm.
Weight	91 g.



2.2 Overview and Function

3 Setup and Operation Instruction

3.1 Setup

1. Put Harmony Universal Glass Plate on top of the 7Chakra Activator Cover tightly.



2. Put the cover on 7Chakra Activator body by placing each drill hole as shown in the pictures.





3.2 Operation

1. To turn on the device, press once to turn on 7Chakra Activator and press and hold to turn off.



- 2. Press on the button **on/off 1 time** to change a program. (Total 9 programs)
 - Program 0: Basic Element Activator





• Program 1: First Chakra (Red Color)





• Program 2: Second Chakra (Orange Color)





• Program 3: Third Chakra (Yellow Color)



• Program 4: Fourth Chakra (Green Color)





• Program 5: Fifth Chakra (Blue Color)




• Program 6: Sixth Chakra (Indigo Color)



• Program 7: Seventh Chakra (Purple Color)



• Program 8: First Chakra to Seventh Chakra and reverse.





3. Press and hold for a few seconds to turn OFF the device.

3.2.1 Charging

1. Plug in the USB Type-C charging cable to the device.



2. The red light indicates the charging status. When the battery is fully charged, the status light will turn green.





4 Fault Diagnosis

Failures	Remedies
unusual/different when it is plugged into power bank	As 7Chakra Activator power requirement is little, its draw power might not successfully trigger the power bank to release full power. Try to plug in phone charging cable into the other power bank USB port to charge your phone to allow power bank to release full power.



Disclaimer

All content found on the Light-mandalas.com Website, Facebook Page, YouTube, including: text, images, video, audio, or other formats are intended for informational, educational and research purposes only and neither Light Mandalas Co. Ltd. nor the publishers of this content take responsibility for possible health consequences of any person or persons reading or following the information in this educational content and is not intended to be a substitute for professional medical advice, diagnosis, treatment or cure. Always seek the advice of your physician or other qualified health professionals with any questions you may have regarding a medical condition.

"No claims other than stress detection and stress reduction may be made"

Light Mandalas products are to be used as a Heart Rate Variability Biofeedback system and Light, Color and Sound therapy, designed for stress detection and stress reduction only. The devices do not evaluate any issue other than stress. Stress can come from many sources; this system uses light and color and sound therapies to reduce stress. Remember, there has never been any reported side effects using light, color and sound therapy anywhere in the world and throughout time.

Notes on the practices of low-level laser therapy (LLLT) and Biofeedback

Low-level laser therapy (LLLT) is considered investigational by the FDA, and no medical claims of cures are permitted in the US; at this time however, low-level lasers are defined within the scope of complimentary medical practices such as physiotherapy, aesthetic, Traditional Chinese Medicine and acupuncture, etc.

The FDA does not regulate Bio resonance tools but they do regulate biofeedback tools and some Bio resonance tools are registered under this category.

*It is a legal requirement at this time that the user does not make any medical claims of diagnosis or cure.

Precaution

Light Mandalas products are working on energetic level. The standard benefit is energy clearance. During the process, your body and mind can be uncomfortable. The symptoms associated with overly rapid clearance of toxins. If those detox symptoms are too strong, you may need to stop using the products. You have to allow the clearance or detox to proceed and you can start to try the products afterwards. However, if the issues still remain the same, it may need to be completely discontinued for your own safety

Shall there be any inquiry, please contact us for further support.

Light Mandalas Co., Ltd. (Thailand Headquarters):

- Light Mandalas Website: www.light-mandalas.com
- > Official: info@light-mandalas.com
- Instagram: @mandalawave9
- > YouTube Channel: Light Mandalas Official
- > Technical Support Email: cservice@light-mandalas.com

Local agents contacts:

- Japan: japan@light-mandalas.com
- Taiwan: lovelight777888@gmail.com
- Indonesia: lightseed2020bali@gmail.com
- West Malaysia: lightworker@healingtech.org
- East Malaysia: malaysia@light-mandalas.com
- Hungary: horesnyibela@light-mandalas.com
- Switzerland, Germany, Austria, and the Netherlands: info@light-mandalas.ch
- France, Spain: france-spain@light-mandalas.com
- USA: usa@light-mandalas.com
- > New Zealand and Australia: tachyonhealing.nz@gmail.com